

- Step 2: Install the new switch with the existing #5 X 1-1/4" PRH Screws (237-5835-00), then solder the wires back onto the lugs.
- **Step 3:** Adjust the new switch, if required. *Ensure blades make contact when the flipper button is pushed in.*

Please phone or eMail with any questions or comments at the below numbers or address.

• 2020 Janice Ave • Melrose Park, IL 60160 • Tel 708-345-7700 (Option 1) • Toll-Free (USA/Canada) 1-800-542-5377 • Fax 708-345-7889 •

Received via Fax? For a better copy, download from our website: www.sternpinball.com/ServiceBulletins.shtml

S.B. Nº 156 Page 1 of 1 Want Service Bulletins by eMail? Request by eMail: parts.service@sternpinball.com